

51	50	49	48	47
46	45		44	43
Výstup (zadní dveře)			42	41
40	39		38	37
36	35		34	33
32	31		30	29
28	27		26	25
24	23		22	21
20	19		18	17
16	15		14	13
12	11		10	9
8	7		6	5
4	3		2	1
	Průvodce			Řidič